

# Quick Start Guide

LVL SAFE<sup>®</sup> Rack Reader and LVL SAFE<sup>®</sup> READ



Install the LVL SAFE<sup>®</sup> Read Application



Connect the LVL SAFE<sup>®</sup> Rack Reader to an USB 3 port



Start the LVL SAFE<sup>®</sup> Read application



Create an Admin User



Place a rack on the scanner and go!

LVL technologies GmbH & Co. KG  
Theodor-Storm-Straße 17  
74564 Crailsheim, Germany  
+49 7951 95613-0  
[info@lvl-technologies.com](mailto:info@lvl-technologies.com)